

# USSA-FFP | Fuzzy Finger™

## Repair Manual

### Instructions for Changing Bristles

The following are instructions for replacing the nylon bristles on the Fuzzy Finger™, should they become worn over time. Before getting started, be sure to follow all appropriate work methods and safety protocols as applicable.

#### Tools Needed

- ★ USSA-FFP-REPAIRKIT
- ★ 3/16" Hex Allen Key
- ★ Needle Nose Pliers (optional)
- ★ Loctite 263

**Step 1** - Place the Fuzzy Finger™ in a bench vise in a **vertical position** as shown to the right. Use of soft jaws is recommended as not to mar the surface finish.

**Step 2** - Using a 3/16" allen key, remove the set screw and set aside.

**Step 3** - Replace existing bristles one at a time and discard.

**Step 4** - Thread in the new bristles. Center the bristles such that the exposed material is even on either side. Tip: Using a pair of needle-nose pliers (or similar), gently depress the inner spring mechanism as shown to the right. This allows the bristles to be threaded in more freely.

**Step 5** - Apply a small dot of Loctite 263 on the threads of the screw before tightening. Replace the set screw and tighten until the bristles are secured. Do not overtighten. Gently tug on each bristle to ensure they are properly secured.

Utility Solutions, Inc.

[www.utilityolutionsinc.com](http://www.utilityolutionsinc.com)

P: 828-323-8914

[sales@utilityolutionsinc.com](mailto:sales@utilityolutionsinc.com)

